



Installation Instructions

Baffle Adapter Kit

For use with WallMaster® Series Air Conditioner

NOTE: This kit applies only to sleeves measuring 19 3/4" deep.

- STEP 1.** Remove old air conditioning from sleeve, clean sleeve interior of debris and examine it for any sign of damaging rust, weak construction, etc. Repair if necessary, then proceed.
- STEP 2.** Check to be sure sleeve has a slight downward slope to outside by placing a level on the raised channel near the front and a large embossment near the rear. (See Figure A)
- STEP 3.** Remove paper backing from double coated foam tape and place baffle assembly vertically against rear grille between louvers (Figure A), making sure notch in baffle is at the top (Figure B). Press seal firmly against rear panel especially at top and bottom.

